




TOP AND CONSOLE PARTS

For Model: WGD8300SW1, WGD8300SB1
(White) (Black)

27" GAS DRYER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Model: WGD8300SW1, WGD8300SB1

(White) (Black)


Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	8578902	Use & Care Guide
	8578904	Guide, Quick Start
	8578834	Tech Sheet
2		Top
	8563730	White
	W10129703	Black
3	W10110973	Harness, Main
4		Panel, Console
	W10099598	White
	W10099631	Black
5	3394427	Clip, Harness
6	8565237	Bracket, Console
7	353424	Connector, Sensor
8	94614	Terminal
9	3936144	Plug, Terminal
10	94613	Terminal
11	3390647	Screw, 8-18 x 1/2
12		Knob
	8574963	White
	W10129067	Black
13	8574968	Channel, Water
14	W10117943	Badge, Assembly
15	3395683	Connector, (Motor)
16	3400238	Screw, 2-28 x 1/2
17	8571955	Assembly, User Interface
18	3400238	Screw, 2-28 x 1/2

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Model: WGD8300SW1, WGD8300SB1

(White) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


CABINET PARTS
For Model: WGD8300SW1, WGD8300SB1
 (White) (Black)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8317340	Cover, Terminal Block	17	8563727	Bracket, Control	39	3388674	Idler Bracket
2	3390814	Screw, 8-18 x 3/8	18	W10121334	Washer, Thrust	40	8519459	Clip, Toe Panel
3	8533974	Screw Ground	19	8574875	Switch, Assembly	41		Toe, Panel
4		Panel, Side (R.H.)	20	690997	Door Tri Ring	8540621	White	
	8565048	White	21	8066115	Cover-Plate	W10112964	Black	
	W10112963	Black	22	8580015	Ramp, Door	42	98129	Screw, 6-20 x 1 1/16
5	3394881	Switch, Broken Belt	23	W10111606	Control Board	43	3390647	Screw, 8-18 x 1/2
6	3357011	Screw, 10-16 x 1/2	24	8572546	Kit, Stack Assembly	44	3387242	Seal, Front Panel
7		Panel, Side (L.H.)	25	8533971	Screw, 8-18 x 5/16	45	3393008	Screw, 10-16 x 1/2
	8565054	White	26	3393657	Restrainer, Belt	46	688983	Screw, 8-18 x 1/16
	W10112962	Black	27	8538263	Motor Assembly 60 HZ.	47	8565059	Panel, Rear
8	3392100	Foot, Dryer	28	3398948	Wire, Jumper (Broken Belt Switch)	48	8565043	Plug, Strip Front Panel
	279810	Foot – Optional (Extended Length Package Of 2) (Not Included)	29	3389729	Pulley 60 HZ.	49	343641	Screw, 10-16 x 1/2
9	660658	Clamp, Motor (2)	30	3387610	Belt, Drive	50	8565046	Base, Cabinet Front Panel
10	3387374	Spring, Idler	31	8529757	Bracket, Burner	51		(Includes Illus. 44)
11	3389420	Retainer, Idler	32	3387118	Bracket, Motor		8580257	White
12		Plug, Multivent 697750 White	33	3401401	Cord, Power		W10129648	Black
	3388309	Black	34	49026	4" – 90° Elbow	52	8565122	Strike, Door (1)
13	3388672	Pulley Assembly	35	693995	Screw, 8-18 x 3/8			
14	3978776	Bracket, Gas Pipe	36	3395532	Exhaust Pipe & Bracket			
15	8066120	Lever, Snap Switch	37	3395534	Exhaust Pipe (Short)			
16	3394081	Wire, Belt Switch	38	3395535	Exhaust Pipe (Long)			
Optional Parts Not Included								
Dryer Exhaust Kit (For Side & Bottom Venting)								
						53	279818	White
							279820	Black

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Model: WGD8300SW1, WGD8300SB1
 (White) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Model: WGD8300SW1, WGD8300SB1
 (White) (Black)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8575325	Shaft, R.H. Thread	19	8575324	Shaft, L.H. Thread	36	3403634	Socket Assembly
2	3390647	Screw, 8-18 x 1/2	20	690997	Ring, Tri	37	697772	Wheel, Blower
3	W10153413	Door, Lint Screen	21	8536973	Roller, Support	38	8573713	Thermal Cut-Off
4	3406653	Harness, Sensor	22	8563728	Exhaust Pipe	39	3394986	Spring, Lint Screen Door
5	3394346	Air Duct Assembly	23	W10153423	Housing, Outlet Assembly	40	8066208	Clip-Spring
6	697813	Seal, Outlet Housing	24	489463	Screw, 8-18 x 5/8	41	695240	Screw, 8-18 x 1/2
7	697814	Seal, Drum Front	25	W10153420	Complete Drum Assembly	42	8577274	Thermistor
8	3934666	Nut, 3/8 x 16(R.H.)	26	W10109200	Screw, 11-16 x 3/4	43	487909	Screw, 8-15 x 1/2
10	3402841	Lens, Drum Light	27	697694	Seal, Drum	44	8544362	Housing, Blower
11	359625	Screw, 8-18 x 1/2	28	3401850	Harness-Gas	45	8066168	Lint Duct Assembly
12	8572105	Clip, Exhaust Pipe	29	90767	Screw, 8-18 x 3/8	46	8573824	Funnel, Burner
13	8533971	Screw, 8-18 x 5/16	30	8519221	Channel Bracket, Rear Bulkhead (2)	47	8573028	Thermostat, High-Limit 205°F (96°C)
14	8529007	Plug, Rear Bulkhead	31	8571651	Bracket, Upper Rear Bulkhead	48	338906	Sensor, Radiant
15	693995	Screw, 8-18 x 3/8	32	3401707	Wire Jumper	49	3387230	Screw, 10-16 x 1
16	W10001120	Nut, 3/8-16 (L.H.)	33	3406124	Bulb, Light	50	W10153409	Baffle, Drum
17	8520836	Bulkhead, Rear	34	3387223	Electrode, Sensor	51	8565061	Bulkhead, Front
18	3387459	Washer, Support	35	8578825	Bracket, Drum Light	52	W10153412	Grill, Outlet
						53	3392519	Thermal Fuse
						54	697770	Seal, Cover Plate
						55	W10049370	Lint, Screen

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


8576353 BURNER ASSEMBLY

For Model: WGD8300SW1, WGD8300SB1

(White) (Black)

USE WITH TYPE 1 - NATURAL

AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

8576353 BURNER ASSEMBLY

For Model: WGD8300SW1, WGD8300SB1
(White) (Black)

USE WITH TYPE 1 – NATURAL
AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES

Illus. No.	Part No.	DESCRIPTION
1	8576353	Burner Assembly 60 Hz. (Type 1) (White Rodgers)
2	688617	Tube, Burner
3	694298	Bracket, Ignitor
4	686590	Ignitor
5	3393909	Screw & Washer (8-32 x 7/8)
6	343641	Screw, 10-16 x 1/2
7	3389871	Base, Burner
8	3387057	Screw, 8-18 x 3/8
9		Orifice, Burner 15418 Type 1 15422 Type 4 (Butane) 234867 Type 4 (Propane)
10	W10118347	Valve, Gas 60 Hz. (Complete) (Includes Pipe & Illus. #7).
11	694421	Screw, 8-32 x 1/2 (2)
12	694538	Bracket, Coil
13	694540	Coil, 60 Hz. (2 Terminal) (Main)
14	694539	Coil, 60 Hz. (Split) (3 Terminal) (Pilot Position)
15	694424	Leak, Limiter
16	694423	Screw, Regulator Adjustment
17	694422	Spring, Regulator
18	3390647	Screw, 8-18 x 1/2
20	239822	Plug, Pipe
25	3387561	Clamp, Pipe
26	3389889	Bracket, Support

Following Parts Not Illustrated


8576846 Conversion Kit
(Type (1)
to Type (4) LPG).

BA-153A

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Model: WGD8300SW1, WGD8300SB1
 (White) (Black)



Illus. No.	Part No.	DESCRIPTION
1	8565119	Plug Strip
2	8578887	Door Hinge Assembly
3	3393258	Screw, 10-16 x 3/64
4	8534044	Screw, 8-18 x 1/2
5	8571839	Cover, Hinge White
	W10129722	Black
6	8579663	Seal, Window
7	8534022	Screw, 8-18 x 1/16

Illus. No.	Part No.	DESCRIPTION
8	W10017850	Screw, 10-24 x 3/64
9	W10044180	Door Intermediate (Outer)
10	8578933	Door Assembly (Inner) (Includes Illus. 1 & 14)
11	355515	Screw, 8-18 x 11/16

Illus. No.	Part No.	DESCRIPTION
12	8571836	Door, Outer Ring White
	W10129706	Black
13	8565117	Window
14	690081	Door Catch Assembly
15	8519354	Retainer-Lower Door,
16	W10108900	Intermediate White
	W10129704	Gray
17	8519356	Retainer-Upper

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Model: WGD8300SW1, WGD8300SB1
(White) (Black)

Illus.	Part	
No.	No.	DESCRIPTION

PAINT, TOUCH-UP (1/2oz.)

72017 White
72302 Black

PAINT, PRESSURIZED SPRAY (12 oz.)

350930 White
786020 Black
350938 Primer, Gray

PAINT, BULK (1 qt.)

799344 White (Uncut)
786302 Black (Uncut)

ACCESSORY PARTS

8529894 Hold Down Kit
8563738 Dry Rack
8522199 Kit, Dryer
Vent Testing
80047 Kit,
Dryer Repair